



ISSUE
 09/03/10 ISSUED FOR PERMIT 1
 10/22/10 CONSTRUCTION 2

HARRELL
 ARCHITECTS, LP

9575 Katy Frwy., #200
 Houston, Texas 77024
 tel: 713.722.7071
 fax: 713.722.7072

CONSULTANTS
 Holste & Associates, Inc
 MEP Engineers
 TDG
 Food Service
 Paul Engineering
 Structural Engineers

PROJECT NAME
LUCA & LEONARDO RESTAURANT

LUCA & LEONARDO
 RESTAURANTE

PROJECT ADDRESS
 20 WATERWAY
 THE WOODLANDS, TEXAS

PROJECT NUMBER
 10018
 SHEET NAME
WINDOW & DOOR DETAILS
 SHEET NUMBER

A8.00

		<p>MOULDING TYPE 'A' ADHERED TO STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE. MOULDING TYPE 'C' ADHERED TO STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE.</p>									
				<p>MOULDING TYPE 'D' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE. MOULDING TYPE 'C' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE.</p>							
				<p>MOULDING TYPE 'A' MOULDING TYPE 'B' MOULDING TYPE 'C' MOULDING TYPE 'D' MOULDING TYPE 'E' MOULDING TYPE 'F' MOULDING TYPE 'G' MOULDING TYPE 'H' MOULDING TYPE 'I' MOULDING TYPE 'J' MOULDING TYPE 'K' MOULDING TYPE 'L' MOULDING TYPE 'M' MOULDING TYPE 'N' MOULDING TYPE 'O' MOULDING TYPE 'P' MOULDING TYPE 'Q' MOULDING TYPE 'R' MOULDING TYPE 'S' MOULDING TYPE 'T' MOULDING TYPE 'U' MOULDING TYPE 'V' MOULDING TYPE 'W' MOULDING TYPE 'X' MOULDING TYPE 'Y' MOULDING TYPE 'Z'</p>							
		<p>MOULDING TYPE 'C' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDE TAPE. MOULDING TYPE 'A' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDE TAPE. FASTEN SNAP-ON COVER TO WOOD TRIM @ 12" O.C. & INSTALL COVER TO COMPLETE.</p>	6" = 1'-0"	11	<p>MOULDING TYPE 'C' MOULDING TYPE 'D' MOULDING TYPE 'A' FASTEN SNAP-ON COVER TO WOOD TRIM @ 12" O.C. & INSTALL COVER TO COMPLETE. DOOR - RE: DOOR SCHEDULE</p>	6" = 1'-0"	7				
		<p>MOULDING TYPE 'E' ADHERED TO EXISTING GLAZING. MOULDING TYPE 'D' ADHERED TO EXISTING GLAZING. SEALANT</p>	6" = 1'-0"	10	<p>EXISTING STOREFRONT BEYOND DOOR - RE: DOOR SCHEDULE</p>	6" = 1'-0"	6	<p>MOULDING TYPE 'J' MOULDING TYPE 'A' MOULDING TYPE 'B' DOOR - RE: DOOR SCHEDULE FASTEN SNAP-ON COVER TO WOOD TRIM @ 12" O.C. & INSTALL COVER TO COMPLETE.</p>	6" = 1'-0"	3	
		<p>MOULDING TYPE 'D' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE. MOULDING TYPE 'C' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE.</p>	6" = 1'-0"	9	<p>DOOR - RE: DOOR SCHEDULE MOULDING TYPE 'A'</p>	6" = 1'-0"	5	<p>MOULDING TYPE 'D' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE. MOULDING TYPE 'C' MOULDING TYPE 'J' DOOR - RE: DOOR SCHEDULE FASTEN SNAP-ON COVER TO WOOD TRIM @ 12" O.C. & INSTALL COVER TO COMPLETE.</p>	6" = 1'-0"	2	
		<p>MOULDING TYPE 'A' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE. MOULDING TYPE 'C' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE.</p>	6" = 1'-0"	8	<p>DOOR - RE: DOOR SCHEDULE MOULDING TYPE 'A'</p>	6" = 1'-0"	4	<p>MOULDING TYPE 'D' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE. MOULDING TYPE 'C' MOULDING TYPE 'J' MOULDING TYPE 'H' DOOR - RE: DOOR SCHEDULE FASTEN SNAP-ON COVER TO WOOD TRIM @ 12" O.C. & INSTALL COVER TO COMPLETE. NEW WINDOW WALL COMPONENT NEW TRIM PIECE MOULDING TYPE 'A'</p>	6" = 1'-0"	1	
		<p>MOULDING TYPE 'A' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE. MOULDING TYPE 'C' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE.</p>	6" = 1'-0"	8	<p>DOOR - RE: DOOR SCHEDULE MOULDING TYPE 'A'</p>	6" = 1'-0"	4	<p>MOULDING TYPE 'D' ADHERED TO EXISTING STOREFRONT W/ INDUSTRIAL STRENGTH DOUBLE SIDED TAPE. MOULDING TYPE 'C' MOULDING TYPE 'J' MOULDING TYPE 'H' DOOR - RE: DOOR SCHEDULE FASTEN SNAP-ON COVER TO WOOD TRIM @ 12" O.C. & INSTALL COVER TO COMPLETE. NEW WINDOW WALL COMPONENT NEW TRIM PIECE MOULDING TYPE 'A'</p>	6" = 1'-0"	1	